How to set brick rack and unit position

Published 01/30/2002

Symptom(s):

How to set brick rack and unit position

Fact(s):

SGI Origin 3200
SGI Origin 3800
SGI Onyx 3200
SGI Onyx 3400
SGI Onyx 3800
SGI Origin 3400

SGI Solution:

The following procedure may be used to change the brick position in a system. For example to change the position of a brick reporting its location to be 004c29 to 014c29, issue the following commands.
(If already in the brick's L1 controller, skip the first step)

```
L2> 4.29 l1
L1> brick rack 014
L1> brick upos 29
L1> reboot_l1
The brick's location is now changed.
```

If the brick does not yet have a brick identification number assigned to it yet, use the port number to issue the l1 command. For example, if the 'config' command show the brick as 127.0.1.1:1:1:

```
L2> config
127.0.0.1:
127.0.0.1:0:0 - 014r19
127.0.0.1:1:0 - 014c07
127.0.0.1:1:1 - ---i--
127.0.0.1:2:0 - 014c10

L2> 127.0.0.1:1:1 l1 brick rack 014
L2> 127.0.0.1:1:1 l1 brick upos 29
L2> 127.0.0.1:1:1 l1 reboot_l1
```

Additional Details

Creation Date	08/31/2001 10:49 AM
Last modification	10/01/2015 02:20 AM
Published Date	01/30/2002
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Workstations • SGI Tezro • O2 • Octane
Categories	• Knowledgebase • Technical Solution